

Nennmaß- bereich über ... bis ...	für Bohrung		für Wellen. Beim Fügen mit einer H8-Bohrung entsteht eine...				
	H8	H8	...Spielpassung			...Übermaßpassung	
			d9	e8	f7	h9	u8
bis 3 mm	+14 0	-20 -45	-14 -28	-6 -16	0 -25	+32 +18	+34 +20
3 ... 6 mm	+18 0	-30 -60	-20 -38	-10 -22	0 -30	+41 -23	+46 -28
6 ... 10 mm	+22 0	-40 -76	-25 -47	-13 -28	0 -36	+50 +28	+56 +34
10 ... 14 mm	+27 0	-50 -93	-32 -59	-16 -34	0 -43	+60 +33	+67 +40
14 ... 18 mm							+72 +45
18 ... 24 mm	+33 0	-65 -117	-40 -73	-20 -41	0 -52	+74 +41	+87 +54
24 ... 30 mm						+81 +48	+97 +64
30 ... 40 mm	+39 0	-80 -142	-50 -89	-25 -50	0 -62	+99 +60	+119 +80
40 ... 50 mm						+109 +70	+136 +97
50 ... 65 mm	+46 0	-100 -174	-60 -106	-30 -60	0 -74	+133 +87	+168 +122
65 ... 80 mm						+148 +102	+192 +146
80 ... 100 mm	+54 0	-120 -207	-72 -126	-36 -71	0 -87	+178 +124	+232 +178
100 ... 120 mm						+198 +144	+264 +210
120 ... 140 mm						+233 +170	+311 +248
140 ... 160 mm	+63 0	-145 -245	-85 -148	-43 -83	0 -100	+253 +190	+343 +280
160 ... 180 mm						+273 +210	+373 +310
180 ... 200 mm						+308 +236	+422 +350
200 ... 225 mm	+72 0	-170 -285	-100 -172	-50 -96	0 -115	+330 +258	+457 +385
225 ... 250 mm						+356 +284	+497 +425
250 ... 280 mm	+81 0	-190 -320	-110 -191	-56 -108	0 -130	+396 +315	+556 +475
280 ... 315 mm						+431 +350	+606 +525
315 ... 355 mm	+89 0	-210 -350	-125 -214	-62 -119	0 -140	+479 +390	+679 +590
355 ... 400 mm						+524 +435	+749 +660
400 ... 450 mm	+97 0	-230 -385	-135 -232	-68 -131	0 -155	+587 +490	+837 +740
450 ... 500 mm						+637 +540	+917 +820